



MADE IN U.S.A.

YAZOO

Parts Manual for


S22CB1 SERIES 22" BIG WHEEL MOWER



**Professional Quality Lawn Care Equipment
since 1945**

Yazoo Manufacturing Company's policy is to improve its products whenever it is possible and practical to do so. In an effort to keep pace with changes in technology, Yazoo reserves the right to make changes or improvements at any time without incurring any obligation to make such changes on products previously manufactured.


HANDLE ASSEMBLY



ASSEMBLY HANDLE ASSEMBLY

ITEM	PART NO.	DESCRIPTION
1	0703-023	Grip, 5/16"
2	1201-114	Bail, Engine
3	1201-113	Bail, Clutch
4	0204-168	Bushing, 5/16 Nylon (2)
5	0301-158	Control, Throttle
6	0401-394	Decal, Traction
7	0209-045	HHCS, 1/4"Cx1-3/4G5
8	0301-160	Cable, Clutch
9	1401-009	Nut, 1/4" Lock (2)
10	0309-020	Clamp, Cable (3)
11	0401-395	Decal, Engine Kill
12	0214-515	Mount, Engine Cable
13	0209-032	HHCS, 1/4Cx1-1/4G5
14	1104-020	Knob, 5/16C (2)
15	0401-399	Decal, Stabilize Machine
16	0209-835	CVHB, 5/16Cx2 (2)
17	0801-024	Handle, Lower
18	0801-025	Handle, Upper
19	0209-084	HWST, 5/16Cx5/8 (2)
20	0209-080	HWST, 5/16Cx3/4 (2)
21	0301-159	Cable, Engine
22	0703-013	Grip, Handle

MOWER DECK ASSEMBLY



MOWER DECK ASSEMBLY


ITEM	PART NO.	DESCRIPTION
1	0401-407	Decal, Vari-Mulch (Commercial)
2	0401-398	Decal, Cutting Height
3	0804-093	Hood (Includes Decals)
4	0209-085	HWST, 1/4Cx1/2 (4)
5	0214-512	Rail, LH
6	0209-084	HWST, 5/16Cx5/8 (12)
7	1608-167	Pulley, Spindle
8	0205-059	Belt, Deck / Spindle
9	1401-069	Nut, 5/8F Jam (1)
10	0213-053	Brace, Spindle
11	0703-012	Grip, 3/8
12	1808-318	Rod, Mulcher Control
13	0214-511	Rail, RH
14	1916-140	Spring
15	0209-080	HWST, 5/16Cx3/4 (3)
16	1303-031	Hinge, Mulcher
17	1808-316	Pivot, Mulcher
18	1401-129	Pushnut, 3/8"
19	1401-020	Nut, 5/16 Hex (4)
20	2301-004	Washer, 5/16 Lock (4)
21	0209-108	HHCS, 5/16Cx3/4G5 (4)
* 22	0806-233	Housing, Spindle Weldment
23	0204-019	Bearing, Spindle (2)
* 24	1904-294	Shaft, Spindle
* 25	0806-341	Housing, Spindle Asm.
26	1806-148	Ring, Tolerance
27	0206-950	Blade, 22" Mulch
28	2301-096	Washer, Bevel
29	1303-029	Plate, Mulcher
30	2301-024	Washer, Flat .50 I.D.
31	0209-083	Bolt, Shoulder (2)
32	2302-010	Wheel, 8x1.75 (2)
33	0209-082	Bolt, Shoulder (2)
34	2301-016	Washer, 1/2" Bevel (6)
35	0214-510	Adjuster, Height RH
36	0214-513	Mount, Wheel RH
37	1401-132	Nut, 3/8C Nyloc (2)
38	0214-514	Mount, Wheel LH
39	0214-509	Adjuster, Height LH
40	0402-011	Deck, 22" Mower
41	0401-118	Decal, USA
42	0401-111	Decal, Cut Finger (2)
43	1401-070	Nut, 5/8F Cenlock Half
44	0101-163	Adapter, Blade
45	0609-015	Flap, Drag
46	1401-133	Nut, 1/4C Hex Nyloc (3)
47	0307-050	Clip, Drag Flap (3)
48	0209-021	HHCS, 1/4C x 3/4 G5 (3)
49	0314-034	Shield, Dust
50	1808-314	Link, Front Lift (2)
51	0902-005	Indicator, Cut
52	1102-013	Key, 3/16 Woodruff (2)
53	0705-056	Guide, Belt

Replaced by kit

~~1107-019~~

1107-027

DRIVE & HEIGHT ADJUSTMENT ASSEMBLY



DRIVE & HEIGHT ADJUSTMENT

ITEM	PART NO.	DESCRIPTION
1	0402-012	Deck, Rear
2	0401-396	Decal, Mulch
3	1913-101	Spacer, Lift Screw
4	0215-184	Bushing, 1/2" Machinery
5	1104-019	Knob, Lift
6	1604-014	Pin, Roll 3/16 x 1-1/4 (2)
7	0209-341	HHCS 3/8Fx2 GR5
8	0209-084	HWST, 5/16C x 5/8 (12)
9	0704-017	Guard, Chain
10	1916-186	Spring, Clutch
11	0214-516	Mount, Clutch Stop
12	1604-167	Pin, Clutch Stop
13	0309-063	Clip, 3/8 Pin (3)
14	0310-007	Clutch
15	0204-087	Bushing, Bronze
16	E270	Engine, 5 h.p. B&S 1/C
17	1604-168	Pin, Whl Driver 1/4 x 1-1/2 (6)
18	1916-049	Spring, Ratchet (6)
19	2302-008	Wheel, Traction Asm. (2)
	2005-006	Tube, Traction (2) (Not Shown)
	2003-006	Tire, Traction (2) (Not Shown)
20	1913-095	Washer, 5/8 Flat (2)
21	1806-149	E-Ring, 5/8 (2)
22	1803-016	Ratchet, RH
23	1604-165	Pin, Roll 3/16 x 1-1/4 HD (2)
24	0209-082	Bolt, Shoulder (2)
25	2301-055	Washer, 1/2 Conical (2)
26	0214-508	Mount, Rear Wheel RH
27	1401-129	Pushnut, 3/8 (6)
28	1913-099	Spacer, Wheel (2)
29	0214-506	Brk't., Axle Mounting LH
30	0214-534	Brk't., Axle Mounting RH
31	1921-012	Support, Clutch
32	0209-120	HHCS, 5/16C x 1-1/4 G5 (2)
33	1401-231	Nut, Tinnerman
34	0209-100	HHCS, 5/16C x 5/8 G5 (4)
35	1605-126	Plate, Tie (2)
36	1401-021	Nut, 5/16C Lock (4)
37	0209-150	HHCS, 5/16C x 2-1/2 G5
38	0214-517	Mount, Spring

ASSEMBLY

ITEM	PART NO.	DESCRIPTION
39	1901-233	Screw, Lift
40	0502-023	Swivel, Height
41	1401-130	Nut, 1/4C TLF
42	0605-900-101	Weldment, Lift
43	0204-084	Bushing, 5/8 Nylon (4)
44	1913-102	Spacer, Axle (2)
45	1904-292	Shaft, Axle
46	1917-057	Sprocket, 48T
47	1102-013	Key, 3/16 Woodruff
48	1901-005	SHSS, 1/4C x 1/4 (2)
49	0305-027	Chain (54Pt)
50	1808-315	Link, Front Lift (2)
51	1808-314	Link, Rear Lift (2)
52	0502-022	Swivel, 3/8 (2)
53	0401-220	Decal, OPEI-90
54	1608-168	Pulley, Engine
55	1401-032	Nut, Hex 3/8F
56	2301-006	Washer, 3/8 Lock
57	0209-318	HHCS, 3/8F x 1 G5
58	1608-170	Pulley, Idler
59	0301-152	Cable, Clutch
60	2301-054	Washer
61	0214-507	Mount, Rear Wheel LH
62	1803-017	Ratchet, LH
63	1102-020	Key, 3/16 Sq. x 3/4
64	1913-300	Spacer, Sprocket
65	1401-020	Nut, 5/16C Hex (3)
66	2301-004	Washer, 5/16 Lock (3)
67	2301-022	Washer, 3/8 Flat
68	1401-032	Nut, 3/8 Nyloc
69	1913-305	Spacer, Idler Pivot
70	0102-155	Arm, Idler w/bushing
71	0215-178	Bushing, Bronze
72	0209-337	HHCS, 3/8Cx1-3/4 Gr5
73	0214-536	Brk't., Spring Mount
74	1916-055	Spring, Idler
75	1401-232	Nut, 5/16C HSWH (2)
76	0209-080	HWST, 5/16Cx3/4 (2)
77	0303-088	Cap, Hub (2)
78	1401-030	Nut, 3/8C Hex

optional parts for loose chain

- 1 - 1808-345 Adjustable Rod - Replaces # 51
- 1 - 0502-022 Nut
- 1 - 1401-129 cup
- 1 - 0309-063 clip